IMPORTANT! When Turning Off the Power...

1 Turn off the POWER switch on the rear of the PX-EH.
If the switch is already off, turn it on and then off again.



2 The shut down will start.
Check the POWER lamp (green) on the front of the PX-EH.

❶ Start blinking (Shut down is started) → ❷ Turn off (Shut down is complete)

All unsaved data are written to the internal or external hard disk drive. Please wait.

3 When the shut down is complete, the power will be cut off automatically and the POWER lamp will turn off.

- If an external hard disk or printer is connected, turn off its power by following the order below: Turn off the power to the PX-EH by following steps 1 to 3 above → Turn off the power to the external hard disk or printer.
- We recommend that you disconnect the power cable from the power socket if the PX-EH will not be used for a prolonged period.

FAQ	http://www.plextor.com/english/support/support_faqs.html
RMA	http://www.plextor.com/english/support/support_warranty.html
E-mail	techsupport@plextor.com
Tel	510.440.2000

If you already have the environment specified below, you can start using your PX-EH simply by making the necessary connections.

You need a network having a DHCP server* equipment (broadband router, router-type DSL modem, etc.), as illustrated below.



* What is the DHCP server?
The DHCP server is an equipment that can automatically assign the IP address to a computer or other equipment on the network.When the PX-EH is connected to a network having a DHCP server, the IP address will be automatically assigned to your PX-EH. Once the IP address is assigned, the PX-EH can be used on the network. (The default setting of your PX-EH allows it to automatically obtain the IP address from a DHCP server).

If you don't have the network environment specified above, are using a Mac computer, or want to add a shared user, refer to the Online Manual provided in the CD-ROM.
(Turn this page for an explanation on how to read the Online Manual.)

If you have the above environment, turn this page to proceed to page 2.

PLEXTOR

PX-EH Series Quick Setup Guide

Before Setting Up...

1 Check the model of your PX-EH.

PX-EH Series

☐ Straight LAN Cable

☐ Manual CD-ROM

☐ AC Adapter

☐ Power Cable

☐ Important Infomation

☑ Quick Setup Guide

2 Check the computer you are using.

Confirm that a LAN interface is installed and operating properly.

Downloaded from www.Manualslib.com manuals search engine

Connecting the PX-EH to a network.

- This PX-EH is designed for installation in vertical orientation. Do not install it horizontally, as it may cause breakdown.
- Connect the PX-EH after confirming that the DHCP server is operating.

1 Set the MDI/MDI-X selector switch on the rear of the PX-EH in accordance with the network equipment to which the PX-EH is connected.



2 Connect one end of the supplied LAN cable to the LAN port of the PX-EH, and then connect the other end to the network equipment.



Always turn on the power to the PX-EH after confirming that the LAN cable is securely connected. If the PX-EH is powered up before the LAN cable is connected, the PX-EH cannot participate in the network properly.

Turn on the power.

1 Connet the AC Adapter to DC of the PX-EH and the power socket.

2 Turn on the POWER switch located on the rear of the PX-EH. If the switch is already on, such as when the PX-EH was shut down from the setup screen after the last session, turn off the switch and then turn it back on.

3 The PX-EH has been powered up when the POWER lamp on the front of the PX-EH turns to a steady green light.
If the POWER lamp does not turn to a steady green light, refer to "Troubleshooting in the Online Manual" provided separately.



A steady green color of the POWER lamp indicates that the setup is complete!
You can now use your PX-EH.

While the PX-EH is operating, do not turn off the power by disconnecting the power cable or turning off the AC tap with switch without completing the shut down process. Doing so may result in breakdown or cause loss of data.

Access the PX-EH.

Example of accessing from a Windows XP computer

1 Click Start, right-click My Network Places, and then click Search for Computers.

2 Enter "PX-EH" under Computer name, and then click the Search button.

3 Double-click PX-EH series "PX-EH", which will be found as a result of search.

4 Double-clicking the disk folder will open the usable folders in the PX-EH.

When a file is copied to this window, it will be saved in the PX-EH folder. You also can access the PX-EH on a computer running other operating software by finding PX-EH. For details, refer to the Online Manual provided in the CD-ROM.

How to Read the Online Manual

The Online Manual is provided as a HTML document.
We recommend that you view the Online Manual in Internet Explorer Version 5.0 or higher.

Windows

1. Set the supplied CD-ROM in your computer.
2. The menu will be displayed automatically.
   If the menu is not displayed automatically, open the CD-ROM from My Computer, etc., and then double-click top.htm

Mac

1. Set the supplied CD-ROM in your computer.
2. When the CD icon is displayed, double-click the icon.
3. Double-click top.htm

Tip

When you open online manual on Windows XP SP2, a pop-up message, "Information Bar", may appear.
If it appear, please check "Do not show this message again" and click "OK". Online Manual will be displayed.

Please click information bar between the toolbar and the content window in Internet Explorer and click "Allow Blocked Content...".

Another pop-up meassage, "Security Warning", appear.
Please click "Yes". You can operate an online manual properly.

Downloaded from www.Manualslib.com manuals search engine